

**SPECIFICATIONS FOR ECO RUBBER & ECO CRETE APPLICATION ON:
CONCRETE ROOFS, RETAINER WALLS AND PATIO SLABS.**

***NB: Refer to MSDS & Product Info sheet before commencement.**

- 1 Remove old product and clean surfaces where necessary to provide a suitable bonding surface. Clean away all organic matter and dust. The area must be grease and oil free. Sand off all peeling paint. Eco Rubber can be applied over Torch On & Malthoid, where it is still in good condition, strip if it is brittle.
- 2 Treat problem areas and cracks with Eco Rubber or Eco Crete, applied by brush or roller. Cracks can be filled with Eco Filler. Prepare up turns with Geo-Textile and Eco Rubber. Take care that the Geo-Textile is completely impregnated with Eco Rubber. Prepare parapets by applying first coat by roller. Use a chalk line to guide "cutting" in on walls.
Eco Bond should be applied to raw concrete surfaces before Eco Rubber application. Eco Bond must be applied by roller and at an average rate of 6m² per Litre. Eco Bond should not make a film on the surface and must penetrate the surface. Eco Bond must NOT be sprayed. It is advisable to use a roller.
- 3 Apply Eco Rubber membrane to surface of roof area in two separate coats with the prescribed airless spray pump. The second coat must be applied at a 90-degree angle to the first. Application rate must be 1 to 1,8 kg per square meter (in total) to obtain the correct dry film thickness (depending on the smoothness of the slab). Apply to all parapets, vertical and horizontal surfaces including flashings.
- 4 Allow at least 24 hours curing.

Note:

Eco Rubber needs at least three hours after completion to dry before rain or dew is expected. Eco Rubber cannot be applied on wet surfaces.

Take care to do a complete RISK ASSESSMENT before any work is commenced.

It is advisable to equip your application team with a cordless drill and petrol operated leaf blower.

DO NOT apply over ceramic floor tiles, tiles must be stripped before application and replaced after curing. Take care that tiles do not cut into or damage the membrane. This applies to re-screeding or installation of a new screed as well.

Eco Crete was formulated for high foot traffic. It should not be applied on areas intended for vehicles.

Depending on surface condition, more than the 1kg per m² application rate may be required.

Make sure that all openings are closed during preparation, DO NOT ATTEMPT to close openings by spraying. This will waste material and the product might run into these openings, creating leaks.

PRODUCT: Eco Rubber & Eco Crete

WE THANK YOU FOR THE OPPORTUNITY TO BE OF SERVICE

