



## SPECIFICATIONS OF ECO RUBBER APPLICATION ON CONVENTIONAL TILE ROOFS.

**\*NB: Refer to MSDS & Product Info sheet before commencement.**

- 1 Remove old product and clean surfaces where necessary to provide a suitable bonding surface. Clean away all organic matter and dust. The area must be grease and oil free. Sand away all flaking paint.
- 2 Reposition tiles that moved out of position back into functional position. Treat problem areas and valleys with Eco Rubber, applied by roller or brush. Mend broken tiles with Geo-Textile and Eco Rubber. Take care that the Geo-Textile is completely impregnated with Eco Rubber. Prepare parapets by applying first coat with a roller. Use a chalk line to guide "cutting" in on walls. Fill all openings greater than 3mm between tiles and ridging tiles with Eco Filler.
- 3 Apply Eco Rubber membrane to surface of roof area in two separate coats with prescribed airless spray pump. The second coat must be applied at a 90-degree angle to the first. Application rate must be 1kg per square meter (in total) to obtain the correct dry film thickness. Apply to all parapets, vertical and horizontal surfaces including flashings.
- 4 Allow at least 24 hours curing.

**Note:**

Eco Rubber needs at least three hours after completion to dry before rain or dew is expected. Eco Rubber cannot be applied on wet surfaces.

Take care to do a complete RISK ASSESSMENT before any work is commenced.

It is advisable to equip your application team with a cordless drill and petrol operated leaf blower.

**Depending on roof condition, more than 1kg per m2 may be needed.**

**Make sure that all openings are closed during preparation. DO NOT ATTEMPT to close openings by spraying. This will waste material and the product might run into these openings, creating leaks.**

**PRODUCT:** Eco Rubber

***WE THANK YOU FOR THE OPPORTUNITY TO BE OF SERVICE***

