



## SPECIFICATIONS FOR ECO RUBBER APPLICATION ON NUTECH BIG SIX ROOFS.

**\*NB: Refer to MSDS & Product Info sheet before commencement.**

- 1 Remove old product and clean surfaces where necessary to provide a suitable bonding surface. Clean away all organic matter and dust. The area must be grease and oil free. Sand away all flaking paint and rust on screws.  
  
Reposition sheeting that moved out of position back into functional position. Replace loose and missing roof screws and add new screws on lap joints (120mm Tek screws and bonded washers). Treat problem areas and valleys with Eco Rubber, applied by roller. Fill all lap and cross joints with Eco Filler. Mend hairline cracks with Geo-Textile and Eco Rubber. Take care that the Geo-Textile is completely impregnated with Eco Rubber. Prepare parapets by applying first coat by roller. Use a chalk line to guide "cutting" in on walls.
- 2
- 3 Apply Eco Rubber membrane to surface of roof area in two separate coats with the prescribed airless spray pump. The second coat must be applied at a 90-degree to the first. Application rate must be 1 kg per square meter (in total) to obtain the correct dry film thickness. Apply to all parapets, vertical and horizontal surfaces including flashings.
- 4 Allow at least 24 hours curing.

**Note:**

Eco Rubber needs at least three hours after completion to dry before rain or dew is expected. Eco Rubber cannot be applied on wet surfaces.

Take care to do a complete RISK ASSESSMENT before any work is commenced.

It is advisable to equip your application team with a cordless drill and petrol operated leaf blower.

**Depending on roof condition, more than 1kg per m2 may be needed.**

**Make sure that all openings are closed during preparation. DO NOT ATTEMPT to close openings by spraying. This will waste material and the product might run into these openings, creating leaks.**

PRODUCT: Eco Rubber

***WE THANK YOU FOR THE OPPORTUNITY TO BE OF SERVICE***

